Part Number: HD-ST8-R0K-S
Description: Classic Solo Saddle
Fitment: 2008 Harley-Davidson Rocker
Revision: 1

Tools Required	Parts List
5/16 Allen key	4 3/8-16 x 1 3/4 x 1/2 black socket head cap screw 4 1/4 x 20 flat Washer 4 3/8 lock washers

1. Start by removing the stock seat from your motorcycle providing access to mounting area for your new saddle. Refer to your owner's manual if necessary.

NOTE: We highly recommend using a removable strength thread lock product such as Loctite®.

2. Corbin's Classic Solo mounts easily to your bike very much like stock. Slide the saddle into place nose first securing the mounting tongue *(Figure 1)* and lower onto the chassis. Secure with the included socket head cap screws, lock washers and flat washers, under the decorative seat skirt, using a 5/16 Allen key *(Figure 2).*


FIG 1


FIG 2

Questions? Give us a holler...
800-223-4332
tech@corbin.com